

LED-Pinball-Display 10017

Board Part Number / Platinenbauteilenummer 2003004 / 2003005

Schematics - Schaltpläne

© 2003 by PinLED





Contents - Inhalt

Page 3 / Seite 3.....	Strobes / Stellen.....	Left Display
Page 4 / Seite 4.....	Strobes / Stellen.....	Right Display
Page 5 / Seite 5.....	Digits / Segmente.....	Left Display
Page 6 / Seite 6.....	Digits / Segmente.....	Right Display
Page 7 / Seite 7.....	Board / Platine.....	Left Display
Page 8 / Seite 8.....	Board / Platine.....	Right Display

!!!!!!! CAUTION / VORSICHT !!!!!!!

**Ensure that the HIGH VOLTAGE FUSES are removed
from the Power Supply Board !**

**Stellen Sie sicher, dass die HOCHSPANNUNGSSICHERUNGEN
von der Spannungsversorgungsplatine entfernt sind !**



Notes: used in 10017 left display only!

Date: 07/13/03

Name: A.Förster

Copyright 2003
by A.Förster




Strobes

PinLED

PN: 2003004




Rev: 02

Boardname:
10016 - 10017



Notes:		This sheet is for the left display only!	
Date:	07/13/03	Digits	
Name:	A.Förster	PN: 2003004	
Copyright 2003 by A.Förster		Rev: 02	
		Boardname: 10016 - 10017	

PinLED



Notes:		This sheet is for the right display only!	
Date:	07/13/03	Digits	
Name:	A.Förster	PN: 2003005	
Copyright 2003 by A.Förster		Rev: 02	
		Boardname: 10018 - 10019	

PinLED

